




KNAPP D3 Daily Dose Dispenser: da blister a blister. Una soluzione innovativa per la preparazione della terapia/paziente


DAVIDE FEDELI


Head Of Operations KNAPP Italia

www.knapp.com


6 Novembre 2025











No deblistering, no open tablets

Tablet carriers with RFID chip


- stabilize the original blisters for an automatic process,
- identify the contents unmistakably,
- store any additional data, such as lot, process data and current quantity.



KiSoft


Central intelligence which organizes and controls all kind of material, data and informations flow.


The realization



The process

- Original blisters are clearly identifiable by carriers and receive all desired data
- No cross-contamination
 - → 100% control in the process
- Pushing individual tablets out of the blister into the blister with complete control
- Sealing and printing still in the machine
- Clean-Room inside the system (already approved on German & UK market)
 (Air-Flow-System)
- Accurate tablet inventory
- No open pills in the workspace





Blister Card – Key Features

Intake times

The single daily columns are structured in different intake times per day

Morning

Noon

Evening

Night




Usage information

The cover sheet can be used for different kind of information and is template based.

Clearly arranged intake days

Arrangement of the intake days from right to left



Intake Cup

Montag, 03.10.22 Mustermann, Max



Easy to handle

The intake cup is small but mighty and serves as a multifunctional aid for taking medicines.


Patient information

Content information

Intake time information

Flap for easy opening of the intake cup







Daily Dose Dispenser USPs



Simplified, lean processes

- · No de-blistering of pills needed
- No manual storing, sorting and picking of pills
- No mandatory final inspection, only random checks



No separate clean room

- Use of original blisters, no bulk material, no dust.
- Minimum tablet drop height
- Integrated dust extraction in the production units



Integrated system solution

- · Out of ONE hand
- Proven and reliable technology from KNAPP
- No need for additional subsystems suppliers

